

Vaccine Distribution Centre

TagAlert® Instructions

The CoolPac shipper or Polystyrene Esky you have received contains a TagAlert®

The TagAlert® is a digital **single use** monitor to be disposed as you would for batteries.

The TagAlert® temperature monitor will indicate if there has been a temperature deviation for the Immunisation Section clinical team to review.

Instructions for reading the TagAlert®

Once you have removed the lid and ice bricks/plates of the CoolPac/Esky you will see the TagAlert®.

Step 1 Hold down the **STOP** button for **5 seconds** and check the TagAlert®.

If the LCD displays an arrow to the ✓ no alarms have been triggered during transit. Remove vaccines and immediately place in vaccine fridge.

Step 2 If the LCD displays an arrow to the ✗ and a number 1, 2, 3 and/or 4, then an alarm has been triggered. Contact the Immunisation Section clinical team on 1300 232 272. Remove the vaccines and immediately isolate the products within your vaccine fridge until instructions have been received from the Vaccine Distribution Centre.



For more information

Opening hours: Mon-Fri 9am to 5pm
Vaccine Distribution Centre
Communicable Disease Control Branch
(08) 7425 7139
healthvaccinedistributioncentre@sa.gov.au
www.sahealth.sa.gov.au/immunisationprovider

OFFICIAL



www.ausgoal.gov.au/creative-commons



Government
of South Australia

SA Health



Government
of South Australia

SA Health